GAME ADJUSTMENTS:

ON THE MAIN PROCESSOR BOARD, LOCATED ON THE LEFT INSIDE WALL (SQUARE BOARD), YOU WILL NOTICE TWO BANKS OF EIGHT DIP SWITCHES.

THE BANK OF DIP SWITCHES NEAR THE FRONT DOOR IS "BANK A".

THE OTHER BANK OF DIP SWITCHES, NEARER TO THE TWO AUDIT BUTTONS, IS "BANK B."

THE DIP SWITCHES ARE SET TO PERFORM THE FOLLOWING (ON A TICKET DISPENSING GAME).

GAME TIME:	30 SECONDS
NUMBER OF SHOTS:	20 SHOTS
COIN/CREDIT:	1 COIN - 1 CREDIT
TICKET SOUND:	OFF
TICKET MODE:	ON
TEST MODE:	OFF
ROW BONUS:	OFF
TICKET/TARGET:	1 TICKET FOR EVERY 2 TARGETS
BOUNS FOR 20 TARGETS:	10 TICKETS

	1	2	3	4	5	6	7	8
BANK A:	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
BANK B:	OFF	ON	OFF	OFF	ON	OFF	OFF	ON

PLEASE USE THE CHART ON THE FOLLOWING PAGE TO CHANGE THE ABOVE VALUES.